

How To Install Your Spa CoverSaver™

Your Gladon Spa CoverSaver is designed to be installed in minutes with minimum effort. To save time, read all directions completely before starting installation.

Tools Required: Tape Measure, Marking Pen and Heavy Duty Scissors.

Step 1: The Cover Saver is designed to float on the surface of the water in your Spa. Using a tape measure, obtain the inside dimensions of your Spa at the normal water line. Make sure you measure at the widest point(s), so the CoverSaver will not be cut too small.

NOTE: If your spa recycles water to the spa above the water line, you will need to consider this and adjust the way you cut the Spa CoverSaver, so water does not end up being pumped on top of the Cover.

Step 2: Use the dimensions obtained in step one to trim the Spa CoverSaver to fit your spa. The Spa CoverSaver may be cut using a heavy duty scissors or a pair of tin snips.

Step 3: Place the Spa CoverSaver on the surface of the water in your Spa. Check the fit of the CoverSaver and trim the material as needed to make any final adjustments desired.

Use With “Shiny” Side
In Contact With The
Water In Your Spa



▲ Important—One side of the Spa CoverSaver has special film on it that protects the CoverSaver from premature deterioration. Place this side (the shiny side) down, so it protects the CoverSaver from the chemicals used in your spa. Your Spa CoverSaver is not intended for use in direct sunlight. UV exposure from sunlight will significantly reduce the life of this product.

GLADON
COMPANY, INC.

310 West Forest Hill Av Oak Creek, WI 53154

www.gladon.com

Copyright 2006 Gladon Company, Inc.